RSI-G-466 TRANSFORMER FURNACE

OPERATION AND MAINTENANCE MANUAL

TABLE OF CONTENTS

SOP, OM&M PLANS	SECTION 1
ECLIPSE BURNERS	SECTION 2
FLAME SAFETY	SECTION 3
GAS VALVES & PRESURE SWITCHES	SECTION 4
TEMPERATURE CONTROLS	SECTION 5
TEMPERATURE CONTROL ACTUATORS	SECTION 6
DRAFT CONTROL	SECTION 7
REMOTE CONTROL	SECTION 8
HYDRAULICS	SECTION 9
TIMERS, OVERLOADS, CONTACTS, RELAYS	SECTION 10
DATA LOGGER	SECTION 11
ELECTRIC SCHEMATIC	SECTION 12
DAILY OPERATION LOG SHEET	SECTION 13
OPERATORS TRAINING CERTIFICATE	SECTION 14

Recycling Services International